


R&D Activities for ILC

Peter Kneisel
Jefferson Lab

Issues[1]

- Design goals for ILC are a gradient of $E_{\text{acc}} = (35 \pm 1.7) \text{ MV/m}, Q = 1 \times 10^{10}$ at 2K
- Presently such performance levels in gradient have been achieved only at DESY in 9-cell cavities, however the spread is much larger both in gradient ($\pm 6 \text{ MV/m}$) and Q-value: $Q = (0.8 \pm 0.3) \times 10^{10}$
- Cavity performance spread is affected by variations in material, surface treatment (EP, BCP) and reproducibility in assembly procedures (contamination)




Note: Red diamonds = Eacc after 120 C baking
 Pink square = Q disease ! Result after fast cool down

Issues[2]

- Limitations are:
 - **Field Emission** \longrightarrow Contamination Control
Remedies: High pressure ultrapure water rinsing, clean room assembly
 - **Magnetic Break-down** \longrightarrow Material QC
Remedies: high purity niobium, eddy current scanning (see talk of A. Gurevich)
 - **Q vs E_{acc}** \longrightarrow “Q – drop”
Remedies: electropolishing, “in-situ” baking

"Q - drop"



Theoretical Dependence [A. Gurevich]



Linear BCS Resistance, $T=2.2\text{K}, \Delta/kT_c=1.85$

Experimental





CEBAF Single cell Chinese Large Grain
 Q_0 vs. E_{acc}



"Q - drop"

Investigation of high field behaviour of Nb cavities

for this purpose a high speed temperature mapping system with ~ 600 thermometers was implemented at Jlab, which can localize "hot spots" on a sc surface at 2K (G. Ciovati, Jlab)



Issues[3]

- Cost Reduction

- Alternative Material

- large grain/single crystal vs polycrystalline

- “streamlining” of procedures

- Improvement in effectivity of cavity shape

- TESLA shape vs Low Loss, Re-entrant shapes

- reaching the magnetic field limit of niobium


- Increasing the real estate gradient

- superstructure

- reduction in length, reduction in # of components

Electropolishing of Niobium


Current oscillation control: innovated by H.Diepers et al. in 1971




EP acid

$\text{H}_2\text{SO}_4 (>95\%) : \text{HF} (46\%) - 10 : 1 \text{ V/V}$


Metal complex salt





Very hazardous Acid



Leveling mechanism by P.A.Jaquet



Horizontally Rotated Continuous EP (HRC-EP)




Advantages

- 1) Larger Cathode Surface Area ⇒ Smooth surface in the whole area
- 2) Easy Hydrogen exhaustion ⇒ Elimination of the hydrogen problem
- 3) Inside EP ⇒ Prolongation of the EP acid life
- 4) Closed system ⇒ Safe System against the hazardous EP acid
- 5) Easy control

“ Very Suitable System for Mass Production”

EP- Systems


KEK/Nomura Plating



DESY




JLab



INFN




February 15, 2006



AARD Marx Panel Meeting
at Fermi Lab

Cornell



Electropolishing- Issues

Even though EP of niobium cavities is being done for several decades there are still gaps in understanding its application for large systems:


- Proper rinsing after ep to avoid field emission (sulfur contamination)
- EP geometry and procedures to avoid pick-up of hydrogen, which leads to Q-disease
- Computer modeling of the process with variables such as cathode geometry, acid flow rate, temperature distribution, current distribution..
- “On – line “ data acquisition and data logging of polarization curves, HF concentration..

An R&D plan has been recently developed in the context of the TTC, relying heavily on single cell testing and it needs to be carried out.


Large Grain/Single Crystal Niobium[1]

CBMM


Ingot "D", 800 ppm Ta



Ingot "A", 800 ppm Ta



Ingot "B", 800 ppm Ta




February 15, 2006

Ninxia



Comparison of Single and Poly Crystal RRR niobium



Ingot "C", 1500 ppm Ta



Wah Chang



G.R.Myneni, Jlab

Heraeus



AARD Marx Panel Meeting
at Fermi Lab

Large Grain/single crystal Niobium[2]


Nb Discs



LL cavity 2.3GHz

$$E_{\text{peak}}/E_{\text{acc}} = 2.072$$

$$H_{\text{peak}}/E_{\text{acc}} = 3.56 \text{ mT/MV/m}$$




Scaled to
1300 MHz

1:1:2 BCP only



Surface Roughness (1)

BCP provides very smooth surfaces as measured by A.Wu, Jlab



RMS: 1274 nm fine grain bcp

53 nm after ~ 35 micron, single Cryst

27 nm after ~ 80 micron, single Cryst

251 nm fine grain ep



app.100 micron removed by 1:1:2 bcp

Large Grain/single crystal Niobium[3]

What are the potential advantages of large grain/single crystal niobium?

- Reduced costs
- Comparable performance
- Very smooth surfaces with BCP, no EP necessary
- Possibly elimination of "in situ" baking because of "Q-drop" onset at higher gradients
- Possibly very low residual resistances (high Q's), favoring lower operation temperature (B.Petersen, ERL 2005)
- Good or better mechanical performance than fine grain material (e.g. predictable spring back..)
- Less material QA (eddy current/squid scanning)

Large Grain/single crystal Niobium[4]

- It is desirable to develop the technology for growing ingots of single crystal niobium
- A workshop on this topic is being organized for November 2006 by Jlab and it will be hosted by CBMM
- The hope is to energize niobium suppliers to develop this technology; however, this most likely will not happen without "incentives"


Cavity Shape- Increasing the Effectivity of a structure[1]

- The ratios of $E_{\text{peak}}/E_{\text{acc}}$ and $B_{\text{peak}}/E_{\text{acc}}$ are determined by the cavity shape
- The limitations in a sc cavity are given by field emission loading $\rightarrow (E_{\text{peak}})$ or by “quench”
 $\rightarrow (H_{\text{peak}})$
- The new shapes (“Low Loss” and “Re-entrant”) reduce $B_{\text{peak}}/E_{\text{acc}}$, thus increasing the accelerating gradient for a given “quench” field (for Nb \sim 190 mT),
- Unfortunately, at the same time is the surface electric field increasing, demanding even better control of contamination

Cavity Shape- Increasing the Effectivity of a structure[2]

J.Sekutowicz


Example: 1.3 GHz inner cells for TESLA and ILC



r_{irisb}	[mm]	35	30	33	
k_{acc}	[%]	1.9	1.52	1.8	field flatness
E_{peak}/E_{acc}	-	1.98	2.36	2.21	max gradient (E limit)
B_{peak}/E_{acc}	[mT/(MV/m)]	4.15	3.61	3.76	max gradient (B limit)
R/Q	[Ω]	113.8	133.7	126.8	stored energy
G	[Ω]	271	284	277	dissipation
R/Q*G	[Ω^2]	30840	37970	35123	dissipation (Cryo limit)

Cavity Shape- Increasing the Effectivity of a structure[3]


K. Saito, KEK




Super-Structure[1]

A Super-Structure combines two multi-cell cavities through a weakly coupling beam pipe into one unit

Standard layout: 9-cell structures separated by 286 mm long tube



SST layout: two 9-cell structures coupled by $\lambda/2$ long tube



24/01/2006

J. Sekutowicz

J. Sekutowicz

February 15, 2006


AARD Marx Panel Meeting
at Fermi Lab

21


Super-Structure[2]

➤ RF-distribution system and Real Estate Gradient (cont'd)

Standard layout:



SST layout saves thousands of these components



Super-Structure[3]

- I. Significantly lower cost of the RF-system (40-50% less components).
- II. 40-50% less Input Couplers, therefore cleaning/assembly/processing time and cost reduced
- III. Tunnel shorter by 5-6%, because of shorter inter-cavity connection
- IV. Less openings in cryostat (40-50%), simplified assembly and design.
- V. Less time for assembly of cryostats in the linac.
- VI. Less LLRF units.
- VII. Remedy to synchronic excitation of dangerous HOMs.

Cons: No much experience with beam (Proof of Principle at TTF is the only test).
More difficult production and cleaning, unless we will have **sc-joint**.
1.8-2 x higher power capability of Input Couplers (fortunately it is $\sim \emptyset^4$).
Cold tuner on He vessel (like the blade tuner), more experience needed.

Super-Structure[4]

Estimate of cost reduction **(Couplers only)**

- Present coupler costs are ~ \$ 30000
- Goal is \$ 10000
- Actual costs maybe in between~ \$ 20000
- Coupler Processing: estimated cost/coupler: \$ 3000

Table III. Potential savings

FPC price	\$ 30000	\$20000	\$ 10000
Savings	\$ 398·10⁶	\$ 292·10⁶	\$ 189·10⁶

Summary

- More effort has to go into development of procedures to achieve reproducibly high performance cavities with small spread in performance
- This means one has to gain a better understanding of the EP process, improve the QA procedures for control of contamination and of material variations
- Control of the costs of a large machine such as the ILC can possibly be achieved by implementation of large grain/**single crystal** high purity niobium and of a super-structure configuration for the accelerator
- **In view of a potential combined cost savings of up to half a billion dollars for the ILC, we believe that it would be a justifiable and a clever decision to invest a few percent of the potential cost savings in these developments.**