


# Surface chemistry and the quality factor of superconducting radio frequency (SRF) cavities

A. Romanenko

# Outline

- SRF cavities
- Cavity quality factor
- Hydrofluoric acid “nanostripping”
- Practical recipe to increase  $Q_0$

# Superconducting RF cavities




SRF high beta cavities of different frequencies



Technology of choice for: ILC,  
Project X, Cornell ERL, CEBAF, XFEL,  
SNS and many other accelerators




ILC 9-cell elliptical cavity



TM<sub>010</sub> mode




# Why (only) surface matters



# Cavity quality factor

Understanding the shape of the Q(H) curve and learning how to control it – main objectives of our research



- Three distinct regions – **low**, **medium**, and **high** field Q-slope

- Respond differently to heat and chemical treatments

- The most dramatic effect - high field Q-slope removed by mild baking – UHV in situ annealing at 120C for 48 hours

$$Q_0 = \frac{\omega U}{P_{\text{diss}}}$$


1.3 GHz bulk niobium cavity

# Surface resistance

$$R_s = R_{BCS}(T) + R_{residual}$$

Residual normal electrons

Known and unknown contributions



Bauer- Review of surface resistance models

$$Q_0 = \frac{\omega U}{P_{diss}} \propto \frac{1}{R_s}$$





To increase  $Q_0$ :  
Minimize all contributions to surface resistance at a required gradient

Need to know what and where in the surface ~40 nm all the contributors are!

# Different ways to explore

- ① Detailed studies of the near-surface material structure (only first  $\sim 40$  nm matter!) and superconducting properties by relevant state-of-the-art techniques - then apply the knowledge to the cavities
  - DOE Early Career Award (A. Romanenko)
- ② Cavity experiments
  - Perform some new treatment/see what happens
    - Further progress in the detailed surface understanding is crucial – what to do with the surface and why? What do we need to achieve?



# Best approach - thermometry and cutout





# Detailed surface studies

- SEM/EDS, XPS
- Laser confocal scanning microscopy
- Elastic Recoil Detection for hydrogen profiling
- Positron annihilation studies – vacancy depth profiling
- Electron Backscattered Diffraction – dislocation density mapping
- FIB preparation of cross-sectional samples for defect structure observation in TEM and EELS analysis
- Local magnetization using single and arrays of microHall probes
- Magneto optical imaging
- Muon spin rotation
  - Bulk (TRIUMF)
  - Surface (Paul Scherer Institute)




Beyond the scope of this presentation

# Cavity “HF rinsing” experiments

- **Purpose:** explore the distribution of losses within the RF layer ( $\sim 40$  nm)
- **Means:**
  - Hydrofluoric acid rinsing as a “nanostripping” method -  $\sim 2$  nm/step
  - Cavity  $Q(H)$  measurements after each HF rinse

# Hydrofluoric acid rinse – “nanostripping”



Each HF/water rinse step consumes about 2 nm of niobium from the top of the RF layer determining the surface resistance and moves deeper into the bulk – depth profiling of the losses is possible

# HF rinse procedure

Filling with HF



5 minutes hold





HF dumping



DI water rinse






# Results on EP fine grain (tumbled)



- ✓ Single HF rinse after mild baking significantly improves medium field  $Q_0$
- ✓ Multiple HF rinse cycles do bring the high field  $Q$ -slope back
- ✓ Onset field is still higher than before baking by  $\sim 25$  mT after total 5 HF rinse cycles
  - ✓ Further rinses in queue


# Simple higher $Q_0$ recipe



- FNAL single cell data -> **single HF rinse** (5 min) followed by water rinse is beneficial for the medium field Q value – gains of up to 35% measured at 70 mT

# Possible interpretation

- Literature – 120C enhances residual resistance; possibly due to suboxide formation
- Single HF rinsing and regrowing oxide – restores residual resistance to pre-bake state while keeping the improvement in  $R_{BCS}$



An estimate of the remaining thickness from the HFQS onset:  
 $125 \text{ mT} * \exp(-h/\lambda) = 100 \text{ mT} \Rightarrow h \sim 8\text{nm}$

# Conclusion

- HF “stripping” studies provide a possible cheap way to raise the  $Q_0$  of niobium cavities
- **Recommendation**: perform HF rinse as a last step before high pressure water rinsing for cavities targeted for CW projects